






7178.0415

Onderdelen informatie
Erzatzteil information
Spare part information
Information de pièces







POS:	Art.No.:	Omschrijving:	Aantal:
1	9289.0280	Iron Cast Chimney	2
2	9289.0275	Top Grate of Cooker	4
3		Worktop	1
4	9289.0270	Burner	4
5		Burner Fixed Part	1
6		Top Tabla Support	1
7		Burner Support Part	
8		Oven Chimney	1
9		Pilot Holder	1
10	9289.0430	Oven Burner	1
11		Oven	1
12	9289.0730	Top Burner Pilot	1
13		L Injector Fitting Part	1
14		Oven Copper Pipe	1
15		Oven Bottom Plate Left	1
16		Oven Bottom PlateRight	1
17		Right Side Panel	1
18		Long type Injector	1
19		Front Support	1
20		Front Panel FixingPart	1
21	9289.0405	Adjustable Legs	4
22		Legs Fixing Part	2
23	9289.0445	Oven Hinge	1
24		Nether Panel	1
25	9289.0435	Oven Gas Valve	1
26		Left Side Panel	1
27		Front Side Panel	1
28		Door	1
29		Front Panel	1
30	9289.0660	Knob	4
31	9289.0075	Gas Valve	4
32	9289.0415	Gas Tank	1
33		Range Pipe	1
34	9289.0420	Oven Grate	1
35		Oven Grate Sliders	2
36		Burner Support Part	2
37		Worktop MiddleSupport	1
38		L Injector Fitting Part	4
39	9289.0290	Injector	4
40	9289.0080	Thermocouple	5
41	9289.0860	Pilot	1
42		Oil collector Sheet	2