





7178.0540

Onderdelen informatie
Erzatzteil information
Spare part information
Information de pièces







POS:	Art.No.:	Omschrijving:	Aantal:
1	9289.0590	Basket Handle	4
2		Basket	4
3	9289.0280	Chimney	1
4		Worktop	1
5		Back Pannel	1
6		Side Panel Right	1
7		Upper Hinge	1
8	9289.0055	Cable Gland	1
9		Cable Fixing Part	1
10		Nether Hinge	1
11		Electrical Inlet Pipe	1
12		Front Support	1
13	9289.0690	Empty Tap	1
14	9289.0405	Adjustable Legs	4
15		Legs Fixing Part	2
16		Front Panel Fixing	1
17		Door Inner Part	1
18		Door Outer Part	1
19	9289.0410	Door Handle	1
20	9289.0650	Knob	2
21		Front Panel	1
22	9289.0130	Main Switch	1
23	9289.0260	Thermostat	1
24		Elc. Installation Fixing Part	1
25	9289.0145	Contactactor	1
26		Electrical Terminal	1
27		Side Panel Left	1
28	9289.0725	Magnet	1
29	9289.0385	Heaters	1
30		Basket Bottom Part	1
31		Basket Bottom Part	1